



SHOWN: WT-60-W 3 KEY · WHITE

3 KEY · 4 KEY

● SPARK WT-60-W · WI-FI TOUCH CURTAIN & SHUTTER SWITCH

Open. Stop. Close. Right from the wall.

The Spark WT-60-W is a Wi-Fi touch switch for motorised curtains and window shutters. A flat glass-look panel with clear touch keys, connected to your home Wi-Fi. Available in 3 key and 4 key.

● Wi-Fi

● Touch keys

● Curtains

● Window shutters

● 3 key · 4 key

● Glass-look panel

● LIVING ROOM


Let the light in.

Open, stop or close your curtains with one touch — stop them anywhere in between.



OPEN STOP CLOSE

WT-60-W • 3 KEY • WARM PLASTER



spark


● BEDROOM

Two motors. One switch.

The 4 key controls two motors — here, the curtain on the left keys and the shutter on the right.





WT-60-W • 4 KEY • SLATE PAINT



spark

● DESIGN

One design. Every wall.



Wall finishes are illustrations. Every WT-60-W shown in white.

● HOW THE KEYS WORK

One motor or two.

3 KEY · ONE CURTAIN OR SHUTTER



OPEN

STOP

CLOSE



OPEN



STOPPED



CLOSED



Press Stop at any point to leave the curtain or shutter part-way.

4 KEY · TWO CURTAINS OR SHUTTERS

MOTOR 1

MOTOR 2



TOP KEYS OPEN · BOTTOM KEYS CLOSE

Pair it the way your room works.

Curtain + shutter · bedroom window

Sheer + blackout · two curtain tracks

Two windows · one switch by the door

KEY SYMBOLS



Open



Stop



Close

CHOOSE YOUR VERSION

Curtains and shutters, your way.

1 MOTOR



3 Key

Open · Stop · Close

2 MOTORS



4 Key

Open · Close, two columns

WHY IT WORKS



Wi-Fi
Connects to your home Wi-Fi network.



Curtains & shutters
For motorised curtains and window shutters.



Touch keys
Tap a symbol to open, stop or close — on a flat glass-look panel.



Clear symbols
Open, stop and close marked on each touch key.

SPECIFICATIONS

Model	Spark WT-60-W
Product	Wi-Fi touch curtain & shutter switch
Variants	3 key · 4 key
3 key	Open · Stop · Close (1 motor)
4 key	Open · Close × 2 columns (2 motors)
Connectivity	Wi-Fi
Keys	Touch
Load	Curtain or window-shutter motor
Panel	Glass-look
Colour	White

PART OF THE SPARK HOME

Pair it with the WT-50-W touch light switch for a matching wall.



SPARK-HOME.COM